


INSTALLAZIONE CON SNODO


DS80SP59-001

LBT80169

IS3050-AA



INSTALLATION AVEC ROTULE




INSTALLATION WITH BALL JOINT

1


Remove sensor cover and take out printed circuit (see steps 1 and 2 in section "installation without ball-joint")

2

Using a screwdriver, force ball-joint passage open, where indicated.




BALL-JOINT COMPOSITION




3

Insert pin in ball-joint guides as shown in figure




4

Insert anti-tamper microchip (optional) as shown in figure and pass the 2 cables in the ball-joint pin




5

Insert connection cable in ball-joint and pass it through the pin: pull out cable for about 5 cm (2 inch).




6

Place ball-joint on sensor with base positioned in order to allow ceiling or wall mounting, according to needs (see figure)



7

Place ball-joint-locking washer on pin (with knurled part facing the pin) and pass it through the cable



8

Select position wanted and screw nut on pin to secure ball-joint on sensor.

